# Windows® 7 Support for Fujitsu Technology Solutions Notebooks and Desktop PCs

Release        4.00
Date           February 2010


**Explanation:**

| i | All systems listed in this document can be easily upgraded to Windows 7. All systems released after the launch of Windows 7 are fully compatible with Windows 7. |

**Full Support**
- System are WHQL certified for Windows® 7 (see also https://winqual.microsoft.com/hcl/).
- Complete WHQL certified for Windows® 7 driver set available.

**Limited Support**
- System works with Windows® 7.
- In some cases Windows Vista® drivers and utilities have to be used for some components.

**No Support**
Fujitsu Technology Solutions does not support older systems not listed in this document.

Please find the latest BIOS and driver versions on our Fujitsu Support pages:
http://support.ts.fujitsu.com/com/support/windows7.html


*Fujitsu Notebooks*

| System | Minimum Required BIOS Version | Level of support |
|---|---|---|
| AMILO Li 3710 / Li 3910 | 1.10 | Full Support |
| AMILO PA-3515 | V1.16 | Limited Support |
| AMILO PA-3553 | V1.16 | Limited Support |
| AMILO PI-3525 | 1.09C | Limited Support |
| AMILO PI-3540 | 1.09C | Limited Support |
| AMILO PI-3625 | 1.0G | Limited Support |
| AMILO Pi 3660 / Pi 3560 | 1.05 | Full Support |
| AMILO Sa 3650 | 1.07 | Full Support |
| AMILO Si 2636 | 1.0H | Supported |
| AMILO Si 2654 | 1.0D | Limited Support |
| AMILO SI-3655 | 1.03C | Limited Support |
| AMILO XA-3530 | 2.08 | Limited Support |
| AMILO XI-3650 | 1.0G | Limited Support |
| AMILO Xi 3670 | 1.0G | Full Support |
| CELSIUS H265 | V1.10 | Full Support |
| CELSIUS H270 | V1.10 | Full Support |
| ESPRIMO Mobile D9500 | V1.06 | Limited Support |
| ESPRIMO Mobile D9510 / D9515 | V1.10 | Full Support |
| ESPRIMO Mobile M9400 | V1.06 | Limited Support |
| ESPRIMO Mobile M9410 / M9415 | V1.10 | Full Support |
| ESPRIMO Mobile U9200 | V1.06 | Limited Support |
| ESPRIMO Mobile U9210 / U9215 | V1.10 | Full Support |
| ESPRIMO Mobile V5505 | A1D | Limited Support |
| ESPRIMO Mobile V5515 | V1.10 | Limited Support |
| ESPRIMO Mobile V5535 | V1.12 | Limited Support |
| ESPRIMO Mobile V5545 | A1D | Limited Support |

| System | Required BIOS Version | Level of support |
|---|---|---|
| ESPRIMO Mobile V5555 | V1.12 | Limited Support |
| ESPRIMO Mobile V6505 | V1.22 | Full Support |
| ESPRIMO Mobile V6515 | V1.19 | Limited Support |
| ESPRIMO Mobile V6535 | V1.22 | Full Support |
| ESPRIMO Mobile V6545 | V1.22 | Limited Support |
| ESPRIMO Mobile V6555 | V1.19 | Full Support |
| ESPRIMO Mobile X9510 / X9515 | V1.10 | Full Support |
| ESPRIMO Mobile X9525 | V1.10 | Full Support |
| Fujitsu A1130 | V1.12 | Full Support |
| Fujitsu M 2010 | V1.15 | Full Support |
| LIFEBOOK E8410 K226-V2xx | V1.15 | Limited Support |
| LIFEBOOK E8410 K226-V4xx | V1.18 | Limited Support |
| LIFEBOOK E8420 (Intel Gfx) | V1.16 for 1.xx / 3.04 for 3.xx | Full Support |
| LIFEBOOK E8420 (nVidia Gfx) | V1.16 for 1.xx / 3.04 for 3.xx | Full Support |
| LIFEBOOK P1610 | V1.15 | Limited Support |
| LIFEBOOK P1620 | V1.06 | Limited Support |
| LIFEBOOK P7230 | V1.11 | Limited Support |
| LIFEBOOK P8010 | V1.08 | Limited Support |
| LIFEBOOK P8020 | V1.12 | Limited Support |
| LIFEBOOK P8110 | V1.07 | Full Support |
| LIFEBOOK S6410 | V1.30 | Limited Support |
| LIFEBOOK S6420 | V1.31 | Full Support |
| LIFEBOOK S6520 | V1.31 | Full Support |
| LIFEBOOK S7210 | V1.09 | Limited Support |
| LIFEBOOK S7220 | V1.15 | Full Support |
| LIFEBOOK T1010 | V1.13 | Full Support |
| LIFEBOOK T4220 | V1.18 | Limited Support |
| LIFEBOOK T5010 | V1.12 for 1.xx / 3.05 for 3.xx | Full Support |
| STYLISTIC ST6012 | V1.13 | Full Support |

*Fujitsu Desktop PCs*

| System | Required BIOS Version | Level of support |
|---|---|---|
| AMILO Desktop LA3420 | VG.0F | Limited Support |
| AMILO Desktop LA3425 | VG.0F | Limited Support |
| AMILO Desktop LA3740 | VG.0F | Limited Support |
| AMILO Desktop LI-3410 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop LI-3420 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop LI-3425 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop LI-3740 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop LI-3745 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop PA-3630 | VG.0F | Limited Support |
| AMILO Desktop PI-3620 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop PI-3630 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop PI-3635 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop PI-3645 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop PI-3750 | 3.0U (AHCI) oder 3.0V (IDE) | Limited Support |
| AMILO Desktop SI-3535 | 1703 | Limited Support |
| CELSIUS M460 | V6.0 R1.12 | Full Support |
| CELSIUS M470 | V6.0 R1.07 | Full Support |
| CELSIUS M470 Power | V6.0 R1.07 | Full Support |
| CELSIUS R550 | V6.10.1.06 | Limited Support |
| CELSIUS R570 | V6.0 R1.07 | Full Support |

| CELSIUS R650 | V6.10.1.06 | Limited Support |
|---|---|---|
| CELSIUS R670 | V6.0 R1.08 | Full Support |
| CELSIUS V840 | V6.10.1.10 | Limited Support |
| CELSIUS W360 | V6.0 R1.18 | Limited Support |
| CELSIUS W370 | V6.0 R1.17 | Full Support |
| ESPRIMO C5720 | V6.0 R1.18 | Limited Support |
| ESPRIMO C5730 E-Star4 | V6.0 R1.17 | Full Support |
| ESPRIMO E3520 | V6.0 R1.04 | Full Support |
| ESPRIMO E5615 nForce4 | V6.0 R1.15 | Limited Support |
| ESPRIMO E5616 nForce4 | V6.0 R1.15 | Limited Support |
| ESPRIMO E5625 MCP78B | V6.0 R1.08 | Limited Support |
| ESPRIMO E5635 | V6.0 R1.04 | Full Support |
| ESPRIMO E5720 iQ33 | V6.0 R1.18 | Limited Support |
| ESPRIMO E5730 | V6.0 R1.17 | Full Support |
| ESPRIMO E5925 iQ35 | V6.0 R1.18 | Limited Support |
| ESPRIMO E7935 | V6.0 R1.17 | Full Support |
| ESPRIMO Edition P2411 | V6.0 R1.15 | Limited Support |
| ESPRIMO Edition P2420 MCP68S | V6.0 R1.04 | Limited Support |
| ESPRIMO Edition P2520 MCP73S | V6.0 R1.06 | Limited Support |
| ESPRIMO P1500 | V6.0 R1.05 | Full Support |
| ESPRIMO P2430 | V6.0 R1.04 | Limited Support |
| ESPRIMO P2440 | V1.45 | Full Support |
| ESPRIMO P2530 | V6.0 R1.06 | Limited Support |
| ESPRIMO P2540 | V6.0 R1.04 | Full Support |
| ESPRIMO P2550 | V6.0 R1.05 | Full Support |
| ESPRIMO P3520 | V6.0 R1.04 | Full Support |
| ESPRIMO P5615 nForce4 | V6.0 R1.15 | Limited Support |
| ESPRIMO P5616 nForce4 | V6.0 R1.15 | Limited Support |
| ESPRIMO P5625 MCP78B | V6.0 R1.08 | Limited Support |
| ESPRIMO P5635 | V6.0 R1.04 | Full Support |
| ESPRIMO P5720 iQ33 | V6.0 R1.18 | Limited Support |
| ESPRIMO P5730 | V6.0 R1.15 | Full Support |
| ESPRIMO P5925 iQ35 | V6.0 R1.18 | Limited Support |
| ESPRIMO P7935 | V6.0 R1.17 | Full Support |
| ESPRIMO Q1500 | R2.02TFS | Full Support |
| ESPRIMO Q5030 E-Star5 | R2.02TFS | Full Support |

**Find out more regarding your installed hard and software:**
To find out if your PC is ready for Windows® 7, please download the Windows® 7 Upgrade Advisor.
With this tool you can scan your notebook or desktop PC for potential issues with your hardware,
devices, and installed programs. It recommends what you have to do before you upgrade your system
to Windows® 7.

http://windows.microsoft.com/en-US/windows7/downloads/upgrade-advisor